



### 1. Downloading UPDATE File ( NOKIA-A.jpg )



Download UPDATE File ( NOKIA-A.jpg ) from website to PC.


### 2. Transferring UPDATE File ( NOKIA-A.jpg ) from PC to Mobile Phone



Transfer UPDATE File ( NOKIA-A.jpg ) from PC to Mobile Phone by micro SD, USB cable, etc. (depending on mobile phone)  
Read the manual of your mobile on how to transfer the picture from your PC to your mobile.

E.g. when using the USB cable, don't forget to install Nokia PC Suite. And when you can't get connection with the PC, try another USB port.

### 3. Updating Car Stereo



#### (1) Adjusting initial setting of car stereo

1. Press SRC and hold until the unit turns off.
2. Press MULTI-CONTROL and hold until the initial setting menu appears in the display.
3. Turn MULTI-CONTROL to select SOFTWARE UPDATE.
4. Press MULTI-CONTROL and DATA WAITING flashes in the display.

#### (2) Transfer the UPDATE File ( NOKIA-A.jpg ) from your mobile phone to your car stereo.

1. Please check the manual of your mobile phone on how to select NOKIA-A.jpg (menu depending on type of mobile phone).
2. Send NOKIA-A.jpg via Bluetooth to your car stereo.
3. DATA WAITING in display of car stereo will be changed to DOWNLOADING, UPDATING and finally to COMPLETED.



### 4. Deleting Registered Mobile Phone in CD-Tuner

1. Press MULTI-CONTROL to display the main menu.
2. Turn MULTI-CONTROL to select CONNECTION.
3. Press MULTI-CONTROL and Turn MULTI-CONTROL to select DELETE PHONE.
4. Select the registered mobile phone and push MULTI-CONTROL left.
5. DELETE YES appears in the display. Press MULTI-CONTROL to delete the registered mobile phone.

### 5. Connecting Mobile Phone

1. Press MULTI-CONTROL to display the main menu.
2. Turn MULTI-CONTROL to select CONNECTION.
3. Press MULTI-CONTROL and Turn MULTI-CONTROL to select BT HANDS FREE.
4. Push MULTI-CONTROL up or down to select NOKIA-A.
5. Press MULTI-CONTROL and connect your mobile phone from the beginning as you can see in the manual of your car stereo.

\*\*\* If you want to connect other Multimedia Player to CD-Tuner via Bluetooth, please disconnect AV Profile from Mobile Phone first, and connect from other Multimedia Player.